

GLASS FRONT MERCHANDISER

VISI-COMBO - BOTTLES, 39" VCB
AND

VISI-COMBO - FOOD, 39" VCF

ILLUSTRATED PARTS MANUAL

L0076, REV. C

AUTOMATED MERCHANDISING SYSTEMS 255 WEST BURR BLVD. KEARNEYSVILLE, WV 25430 304-725-6921 - Fax 304-725-6983 INTERNATIONAL A.M.S. S DE RL DE CV KM. 9 CARR. AL CASTILLO NO. 8200 MPIO. DE EL SALTO, JAL. MEXICO 45680 5233-3-6-88-07-17 - Fax 5233-3-6-88-13-14

www.amsvendors.com - e-mail: info@amsvendors.com

AMS Glass Front Merchandiser 39-VCB and 39-VCF Illustrated Parts Manual

Table of Contents

SECTION		PAGE
INTRODUCTION		
Table of Co General Intr Manual Org Merchandis	roduction	3 4 4 5
CABINET PARTS		
	vers and Screens d Parts Assembled for VCB and VCF Vendor	6 8
CHILLER		
	s – Side View s – Top View	12 14
DOOR PARTS		
Door, Hinge Door, Hopp	Bay nal Front and Sides es and Glass er with Sensit I System er with Sensit II System	16 20 24 26 28
ELECTRICAL HARNESSI	ES	31
TRAYS AND PARTS		
1.5" Helix T Bottle Tray Gum and M Helixes	•	50 52 54 58 60

GENERAL INTRODUCTION

The purpose of this manual is to give our customers a way of identifying major service parts for repair and replacement. The illustrations and parts list in this manual are for identification of these service parts only.

Illustrations of these major parts are keyed with our part numbers. The illustrations help identify the general design, position and orientation of these parts. The note section may also give important information.

Please refer to the section on merchandiser identification on the following pages. Without the model style and serial number it may be difficult to identify the required part.

Parts should be ordered from your distributor.

It is our intent to assist our customers with up-to-date documentation. However, this manual may not show all parts, variations or changes. Some parts may be shown slightly out of scale. This manual is itself subject to change without notice. If any errors are found, please notify AMS so the correction can be included in later revisions. Engineering data and third party information are generally not included. The graphical data, group assembly data, parts, part assembly, parts breakout information and tabular data conveyed by this manual is proprietary and belongs to AMS, and holders without prior consent of or without knowledge of and by AMS must surrender this data immediately.

All measurements are in inches except where specified as Metric.

MANUAL ORGANIZATION

This manual is divided into sections representing the general parts of our merchandisers. Each section is further divided into the various subsections or subassemblies of the machine. Each subsection leads off with one or more illustrations showing the parts. Each part shown is identified with the part number.

After the illustrations, the part number in the illustration is paired with our drawing description or title for that part. In some instances there may be multiple parts to choose from. However, the correct service or repair part for the style of merchandiser must be selected. There is a note section where additional information may be found.

A quantities column in the list provides information on the total quantities required for each set-up as shown. Some assemblies are fabricated as a unit at AMS and are replaceable only as a complete assembly. Optional parts identify parts contracted for and installed in the factory at AMS.

This manual contains model and style information for a vendor as found in previous revisions or parent manuals, including corrections. It may also contain additional and new information, especially if it is specific to your new vendor. Previous revisions of this manual should be kept for use with the vendor it was issued for.

MERCHANDISER IDENTIFICATION

When requesting service, replacement parts or technical assistance, please use the **Model Number**, **Serial Number** and **Date Code**, found on the Serial Plate (Refer to Figure 1) affixed to the merchandiser. The plate is usually located to the side of the window. The information contained on this plate is necessary to determine what parts, kits, or maintenance apply to your vendor.





Figure 1. Example of Serial Plate

Model Number Breakdown




Example: AMS35 VCB means it is an Automated Merchandising Systems merchandiser, **35**" wide, with the cabinet trays and columns configured for food, bottles and/or milk –VCB or VCF.

VCB indicates Visi-Combo - Bottles. Chilled bottle items are dispensed from the lower trays, and above a dividing bulkhead chilled snack items are dispensed (Not for H&S items).

VCF indicates Visi-Combo – Food. Perishable food items are kept within Health and Safety temperature limits prior to vending.


Serial Number and Date Code Breakdown



Example: 1203-1010-B3 is translated as U.S. built 1 machine number 203 on production run number 1010 manufactured in the third quarter (C) of 2004.

The Sequential Production Number of machines built in the U.S. starts with the number 1 or any odd number. The Sequential Production Number of machines built in Mexico starts with the number 0 or any even number.


CABINET COVERS AND SCREENS ILLUSTRATION



	CABINET COVERS AND SO	CREENS PA	RTS LIST
PART NO.	PART DESCRIPTION	QTY	NOTES
1	39" Cabinet Wrapper	1	Cabinet Wrapper - Outside
2	39" Cabinet Tank	1	Cabinet Tank - Inside
3000	Screw, Sheet Metal, TEK 8-18	8	Quantities For One Trim
3009-02	Rivet, Pop, Steel, 1/8" (1/3" Long)	8	Quantities For One Cover
21040 Screen, Rear Chiller Hole, 8 Mesh			With H&S - 1/8 x 1/8 Welded Galvanized Also Used for Bottom Hole
20185	Tank, Rear Chiller Hole Cover	1	Also Used for Tank Bottom Cover
20187	Wrapper Rear Chiller Hole Cover 39" Black		
20187-01	Wrapper Rear Chiller Hole Cover 39" Coca Cola Red	1	Also Used for Wrapper Bottom Cover
20187-02	Wrapper Rear Chiller Hole Cover 39" Bimbo Blue		
20275	Trim, Rear Chiller Hole 39"	1	Steel Trim Holds Screens Also Used for Bottom Hole
20279	Screen, Rear Chiller Hole	1	W/O H&S - ¼ x ¼ Welded Galvanized Also Used for Bottom Hole
20600	Screen, Rear Insect (39")	1	18x16 Mesh, .011, Aluminum Also Used for Bottom Hole
20601	Corner, Insect Screen	2	Obsolete (ECN 1112)-Not Used
21308	Expanded Metal, Rear Chiller Hole (39")	1	16 GA. Flattened Galvanized Carbon Steel Usually Used Over Rear Screen Only

General Note: The rear opening and the bottom opening are the same size on 39" Cabinet. All screen materials are fitted into trim parts, and trim parts are attached to the outside of the cabinet. The combination of mesh and screens used may differ between merchandisers. Covers to seal the cabinet are always attached inside and outside the cabinet at the same time, after removing the trim.

CABINET PARTS FOR VCB AND VCF ILLUSTRATION




CABINET PARTS FOR VCB AND VCF PARTS LIST				
PART NO.	PART NAME	QTY	NOTES	
3000	Sheet Metal Screw TEK #8-18	54	(Estimated Qty)	
3006-08	Nut, 8-32, Hex, Machine Screw	1	For Attaching Power Harness	
3007-06	Screw, 5/16-18, Type F	16	4 Per Leg	
3009-04	Rivet, Pop, Steel, 1/8 x 1/4 Grip	10	For Lock (Est. Qty)	
3010	Nut, Square, Machine Screw, ½"-13	1	For Lock	
3017-10	Washer, #10 SAE Flat	4	For Power Harness/Door Stop Cable	
3018	Sheet Metal Screw, ¼"	3	For Lock	
3057	Inlet, Panel Mount, IEC	1	Snapped Into Place at Rear of Cabinet	
3060-10	Nut, 10-32, W/Nylon Insert	2	For Both Ends of Door Stop Cable	
3061-06	Screw, 10-32, x 3/4, Phillips Pan Head	2	For Door Stop Cable	
3067	Spacer, 0.192 ID x 0.125 Length x 3/8 Dia.	2	For Door Stop Cable	
3084-10	Screw, Sems, 8-32	1	For Power Harness	
3113	Push Nut, 3/16" Stud	2		
3133	Assembly, Fuse Holders and Fuses	1	For 3AG Fast Blow Fuse Only	
3284	Switch, Rocker, On/Off	1	For 24VAC Circuit Control	
20019	Leg, Roller Bracket	1		
20121	Leveling Leg	5	Cabinet To Be Leveled Using All Legs	
20135	Lock Flange	1	For Lock	
20136	Lock Cage	1	For Lock	
20177	Roller, Molded (Nylon)	1		
20213	Flange, Right Vertical	1		
20291	Cover Plate, Hinge Hole, Ver. 2	1	For Top Hinge Bolts	
20292	Shipping Board	1	Right Side 40" Long	
20292-2	Shipping Board	1	Right Side 38-3/8" Long	
20292-01	Shipping Board	1	Left Side 40" Long	
20292-03	Shipping Board	1	Left Side 38-3/8" Long	
20321	Cover, IEC Inlet	1	For Securing Power Cord Grommet	
20349	Assembly, Cabinet, 39", Service	1		
20362	Rail Mount, Left Vertical (3")	1		
20481	Extension, Left Vertical Rail Mount	1		
20608	Cover, Power Cord	1	Optional For Securing Power Cord	
20693	1" Bracket	4	For Securing Visi-Combo Bulkhead	

20790	Bulkhead, Visi Combo Cabinet, Lot Temp (35")	1	For Visi-Combo Option
20880	Cover Plate, Transformer, Low Temp	1	
20882	Cover Plate, Fixed Upper, Low Temp	1	
20883	Cover Plate, Fixed Lower, Low Temp	1	
20907	Bulkhead, Right Rail Mount, Low Temp	1	
21053	Stiffener, Right Vertical Rail Mount	1	
21079	Cable Assembly, Door Stop, Modified	1	Mounting Hardware Not Shown
21087	Plate, Door Switch Spring	1	
21122	Assembly, Leg, Front Hinge With Thread Cover	1	
21123	Assembly, Leg, Left Front with Thread Covers	1	
21124	Assembly Leg, Rear with Thread Covers	2	
21125	Assembly, Cabinet, 39", Low Temp	1	
21250	Shaft, Headed Roller (Zinc Plated)	1	
21476	Rail Mount, Right Vertical, Low Temp	1	
21479	Plate, Fuse Holder, Socket And Power Switch Mount	1	
21509	Decal, 24V Fuse, Ver. 2	1	
21691	Enclosure, Fan Switch, Ver. 2	1	Normally Open Switch, P/N 3199
22005	Assembly, Right Rail Mount Door	1	
22071	Assembly, Cabinet, Version 04, (39")	1	
22072	Assembly, Cabinet, Service, Version 04 (39")	1	

THIS PAGE INTENTIONALLY LEFT BLANK


CHILLER PARTS ILLUSTRATION - SIDE VIEW



CHILLER - SIDE VIEW PARTS LIST					
PART NO	PART DESCRIPTION	QTY	NOTES (See Note A Below)		
1	Cabinet Tank Wall, Left Side		For Reference		
2	Cabinet Tank Wall, Right Side		For Reference		
3	Chiller Unit (Condenser, Heat Exchanger, Evaporator)	1	For Reference, See Note A.		
3000	Sheet Metal Screw TEK #8-18	46	(Estimated Qty)		
3018-06	Screws, ¼ x ¾, Self Tapping, Hex Head	2	For Attaching To Walls		
3018-08	Screws, ¼ x 1, Self Tapping, Hex Head	6	For Attaching To Floor		
3106	Evaporator Fan/Motor Assembly, 220V, 50Hz, 1 Phase	4	Check Voltage!		
3107	Evaporator Fan/Motor Assembly, 110V, 60Hz, 1 Phase	ı	Check Voltage!		
20312	Evaporator Mounting Panel, Low Temp	1	Use With 21076 Pan		
20316	Evaporator Cover Plate, Low Temp	1			
20317	Evaporator Plenum	1	Standard Plenum		
21076	Pan, ½" Evaporator Drain	1	Soldered Pan		
21077	Base, ½" Evaporator Drain Pan	1	Use With 21076 Pan		
21424	Bracket, Temperature Sensor, Sensit II	1			
21778	Pan, Evaporator Drain, Stamped Steel	1			
21990	Base, Stamped, Evaporator Drain Pan	1	Use With 21778 Pan		
21991	Evaporator Mounting Panel, Stamped Drain Pan	1	Use With 21778 Pan		
22085	Plenum for Visi-Combo	1_	Use under Visi-Combo Bulkhead		
22093	Housing, Chiller Housing, Low Temp	1			

NOTE A: Chiller assemblies are charged with refrigerant and are replaceable only as an assembly.


CHILLER PARTS ILLUSTRATION - TOP VIEW



CHILLER TOP VIEW PARTS LIST					
PART NO	PART DESCRIPTION	QTY	NOTES (See Note A Below)		
1	Cabinet Bottom	1	For Reference		
2	Inside Cabinet Wall, Right Side	1	For Reference		
3	Cold Air Plenum Wall	1	For Reference		
4	Condenser Air Inlet Screen Under Chiller	1	For Reference		
5	General Outline of Chiller Housing	1	For Reference		
3034	Split Insulation Tubing	1	Heat Exchanger Tubing Insulation, 7 Foot		
3065	Fan, Condenser Assembly, 220V, 50Hz, 1 Phase	1	Check Voltage!		
3093	Sponge (Condenser Drain Pan)	4			
3106	Evaporator Fan/Motor Assembly, 220V, 50Hz, 1 Phase	1	Check Voltage!		
3107	Evaporator Fan/Motor Assembly, 110V, 60Hz, 1 Phase	1	Check Voltage!		
3108	Fan, Condenser Assembly, 110V, 60Hz, 1 Phase	1	Check Voltage!		
3252-12	Tubing, ½", Clear, Flexible	1			
3254-06	Tubing Clamp	1	Clamps 22070 Tubing To Pan		
20144	Refrigeration Harness	1	Use With Both 110V or 220V Systems		
20307	Condenser Drain Pan	1	Pan With Soldered Corners		
20312	Evaporator Mounting Panel, Low Temp	1	Use With 21076 Pan		
20963	Assembly, 1/2 Plus H.P. Chiller, 120V (39"), AMS (WV)	1	Assembly Only		
21076	Pan, ½" Evaporator Drain	1	Pan With Soldered Corner		
21077	Base, ½" Evaporator Drain Pan	1	Use with 21076		
21103	Assembly, 1/2 Plus H.P. Chiller, 240V (39"), AMS (WV)	1	Assembly Only		
21599	Assembly, 1/2 Plus H.P. Chiller, 120V (39"), AMSINT (MEX)	-	Assembly Only		
21778	Pan, Evaporator Drain, Stamped Steel	1			
21990	Base, Stamped, Evaporator Drain Pan	1	Use With 21778 Pan		
21991	Evaporator Mounting Panel, Stamped Drain Pan	1	Use With 21778 Pan		
22048	Condenser Drain Pan, Formed	1	Stamped		
22070	Tubing, ½", Clear, Flexible, Vinyl (17")	1	Drains Evaporator Condensate		

NOTE A: Chiller assemblies are charged with refrigerant and are replaceable only as an assembly.

DOOR COIN BAY ILLUSTRATION




DOOR COIN BAY PARTS LIST						
PART NO.	PART NAME	QTY	NOTE			
1	Assembly, Foamed Door, 39"	1	See Door External Parts for Door P/N's			
1	Program Chip	1	Contact AMS for your application.			
3000	Screw, Sheet Metal TEK 8-18	18				
3005-04	Carriage Bolt, #10-24,1/2"	5				
3006-10	Nut, Hex, Machine Screw, #10-24	5				
3009-04	Rivet, Steel, 1/8", Black, 3/8"-Grip Length 1/4"	10				
3017-06	Washer, Flat Steel, SAE Std., #6 Screw 5/32	10				
3017-10	Washer, Flat Steel, SAE Std., #10 Screw 7/32 X 1/2	2				
3036	Switch, Panel Mount Rocker	1				
3037-1	PC Board Support (3/16")	6				
3038	Rivet, Nylon, Trim	5				
3278	Circuit Board Support	4	Sensit II			
20081	Scavenger Button	1				
20007	Electronic Control, (Snack/Food Only)	1	Sensit I, Obsolete, See 20818			
20008	Display Board, Digital	1	Sensit I Only			
20099	Coin Chute, Insert	1				
20100	Coin Chute Cover	1				
20129	Coin Box Bulkhead	1				
20281	Door Stiffener, Bottom (Without Fuse and Switch)	1	Obsolete, See 20281			
20339	Assembly, Coin Chute	1				
20340	Assembly, Coin Cup	1				
20343	Coin Door Assembly, Lower	1				
20400	Door Stiffener, Upper (With Fuse and Switch)	1	Obsolete, See 20706			
20526	Assembly, Coin Box	1				
20631	Bracket, Scavenger Stop	1				
20673	Electronic Control (Snack/Food or Visi-Combo)	1	Sensit I, Obsolete, See 20818			
20706	Door Stiffener, Upper, Without Fuse And Switch	1				
20707	Door Stiffener, Bottom With Switch	1				
20751	Assembly, Scavenger	1				
20752	Assembly, Coin Door, Upper (51")	1				
20762	Assembly, LED Mount Bracket	1	Sensit I Only			
20818	Electronic Control (With Bottle Connector)	1	Sensit I Only			

21342	Control Board, Sensit II	1	Sensit II
21423	Bracket, Display 80mm x 36mm	1	Sensit II
21431	Display, 2 Line, 16 Character, Sensit II	1	Sensit II
21942	Mounting Panel, Changer, Multi-Use	1	

THIS PAGE INTENTIONALLY LEFT BLANK

DOOR, EXTERNAL PARTS ILLUSTRATION




	DOOR, EXTERNAL PARTS LIST				
PART NO.		PART NAME	QTY	NOTE	
	21338	Assembly, Foamed Door, Low Temp (39")		No Trim Option	
	21339	Assembly, Foamed Door, Low Temp W/Trim Holes (39")		3122, 20567-01, 21404-07, 21522-07, 21567-07, 20568-01, 21040-05, 21522-05, 21567-05 Used For This Door	
	21340	Assembly, Foamed Door, Low Temp W/WC Holes (39")		Items 300, 3038, 3122, 3156-10, 20451-04, 21404-04 21522-04, 21567-04, 21401-04, 21535-04, 21401-05, 21535-05, 21401-06, 21535-06, 21401-07, 21535-07 Used For This Door	
	21341	Assembly, Foamed Door, Low Temp W/WC Holes W/O Trim Holes (39")		No Trim Option. 20547, 20547-01, 20547-02, 20547- Used on This Door	
	21482	Assembly, Door (39"), Low Temp, Less Options		No Trim Option No Trim Option	
	21493	Assembly, Foamed Door, Low Temp (39"), Coke Red	1		
4	21494	Assembly, Foamed Door, Low Temp W/Trim Holes (39"),Coke Red		3122, 20567-01, 21404-07, 21522-07, 21567-07, 20568-01, 21040-05, 21522-05, 21567-05 Used For This Door	
1	21495	Assembly, Foamed Door, Low Temp W/WC Holes (39"),Coke Red		Items 3000, 3038, 3122, 3156-10, 20451-04, 21404-21522-04, 21567-04, 21401-04, 21535-04, 21401-05, 21535-05, 21401-06, 21535-06, 21401-07, 21535-07 Used For This Door	
	21496	Assembly, Foamed Door, Low Temp W/WC Holes W/O Trim Holes (39") Coke Red		No Trim Option. 20547, 20547-01, 20547-02, 20547- Used on This Door	
	21520	Assembly, Foamed Door, Low Temp (39")		3122, 20567-01, 21404-07, 21522-07, 21567-07, 20568-01, 21040-05, 21522-05, 21567-05 Used For This Door	
	21521	Assembly, Foamed Door, Low Temp W/WC Holes (39")		Items 3000, 3038, 3122, 3156-10, 20451-04, 21404-21522-04, 21567-04, 21401-04, 21535-04, 21401-05 21535-05, 21401-06, 21535-06, 21401-07, 21535-07 Used For This Door	
	21620	Assembly, Foamed Door, Low Temp, Plastic Doubler, (39")		See Note A Below. No Trim Option	

	21621	Assembly, Foamed Door, Low Temp, Plastic Doubler, W/Trim Holes (39")		See Note A Below. 3122, 20567-01, 21404-07, 21522-07, 21567-07, 20568-01, 21040-05, 21522-05, 21567-05 Used For This Door
1	21622	Assembly, Foamed Door, Low Temp, Plastic Doubler, W/WC Holes (39")	1	See Note A Below. Items 3000, 3038, 3122, 3156-10, 20451-04, 21404-04, 21522-04, 21567-04, 21401-04, 21535-04, 21401-05, 21535-05, 21401-06, 21535-06, 21401-07, 21535-07 Used For This Door
	21623	Assembly, Foamed Door, Low Temp, Plastic Doubler, W/WC Holes W/O Trim Holes (39")		See Note A Below. No Trim Option. 20547, 20547-01, 20547-02, 20547-03 Used on This Door
3000	Screw, S	Sheet metal, TEK 8-18	28	For Use With 21404, 21522, 21567
3011	Self Thre	eading Nut, ¼" Stud	8	For securing Escutcheon
3038	Rivet, Ny	rlon, Trim	40	For Use With 20567-01, 20568-01, 20451-03, 20451-05, 20451-06, 20451-07
3122	Striping Tape, 1/4" Black (Optional for Riveted Aluminum)		21'	See Note B. Use With 20567-01, 20568-01, 20451-04, 20451-05, 20451-06, 20451-07,
	Rivet, Aluminum, 1/8" Diameter, Natural (5/8" Grip)		15	For Use With 20567-01, 20568-01, 20451-03, 20451-05, 20451-06, 20451-07
3172-02	Rivet, Aluminum, 1/4" Diameter, Natural (1/4" Grip)		15	For Securing Window Covers
20082	Escutcheon		1	
	Button		20	
	T-Lock A	Assembly (Lockset And Keys 20131)	1	
	Lockset And Keys		1	
21241	Assembly, Membrane Switch, 4x5, Alphanumeric		1	
20259	Assembly. Vend Eyelet, (39")		1	
20330	Trim, Ext	truded Edge (20330-01 and -02)	2	
		ıminum #1, 29.19	3	See NOTE A Below
	Trim, Alu	ıminum #1, 63.25	1	See NOTE B Below
		ıminum #1, 30.17	1	See NOTE B Below
20451-07	Trim, Aluminum #1, 29.48		1	See NOTE B Below
	Window Cover, Polycarbonate (39"), .110 Thick Window Cover, Polycarbonate (39"), .180 Thick			
20547-01				
		Cover, Polycarbonate (39"), .234 Thick	1	
20547-03	MR-10 S	Cover, Polycarbonate (39"), .234 Thick, cratch Resistant		
	Trim, Riveted Aluminum #1 (34.95)		4	See NOTE B Below
20568-01	Trim, Riveted Aluminum #2 (63.075)		2	See NOTE B Below


21401-04	Trim, Insert, Plastic, Black	3	Use With 21404-04 and 21522-04	
21401-05	Trim, Insert, Plastic, Black	4	Use With 21404-05 and 21522-05	
21401-06	Trim, Insert, Plastic, Black	1	Use With 21404-06 and 21522-06	
21401-07	Trim, Insert, Plastic, Black	1	Use With 21404-07 and 21522-07	
21404-04	Trim Base, W/Holes, Aluminum (Natural)	3	See NOTE C Below	
21404-05	Trim Base, W/Holes, Aluminum (Natural)	1	See NOTE C Below	
21404-06	Trim Base, W/Holes, Aluminum (Natural)	1	See NOTE C Below	
21404-07	Trim Base, W/Holes, Aluminum (Natural)	1	See NOTE C Below	
21522-04	Trim Base, W/Holes, Painted (Black)	3		
21522-05	Trim Base, W/Holes, Painted (Black)	1		
21522-06	Trim Base, W/Holes, Painted (Black)	1		
21522-07	Trim Base, W/Holes, Painted (Black)	4		
21535-04	Trim, Plastic Insert, For Recessed Base	3	Use with 21567-04	
21535-05	Trim, Plastic Insert, For Recessed Base	4	Use with 21567-05	
21535-06	Trim, Plastic Insert, For Recessed Base	1	Use with 21567-06	
21535-07	Trim, Plastic Insert, For Recessed Base	1	Use with 21567-07	
21567-04	Recessed Trim Base With Holes	3	See NOTE D Below	
21567-05	Recessed Trim Base With Holes	1	See NOTE D Below	
21567-06	Recessed Trim Base With Holes	1	See NOTE D Below	
21567-07	Recessed Trim Base With Holes	4	See NOTE D Below	
GENERAL NOTE	Trim Packages, Window Cover Packages and other options co	ntracted for and	I installed at AMS may not apply to your vendor.	
NOTE A	Assembly, Foamed Door, Low Temp, Plastic Doublers are production parts installed on merchandisers 0001-1119 through 0017-1119, and 0001-1121 and after.			
NOTE B	Trim Parts 20567-01, 20568-01, 20451-03, 20451-05, 20451-06, 20451-07 and 3122 were production parts prior to vendor numbers 0238-1106 C2, and also for vendors 0001-1107 C2, 0067-1107 C2 through 0071-1107 C2 and 0102-1107 C2 through 0112-1107 C2.			
NOTE C	Trim parts 21404 Trim Base, W/Holes, Aluminum (Natural), 21401 Trim, Insert, Plastic, Black, and 21522 Trim Base, W/Holes, Painted (Black), became production parts installed on merchandiser 0238-1106 through 0243-1106, 0002-1107 through 0066-1107, 0072-1107 through 0101-1107, 0001-1108 and after. Prior parts are no longer being installed.			
NOTE D	Trim parts 21567 Recessed Trim Base With Holes (35" and 39" parts installed on merchandiser 0084-1121 and after. Prior part	'), and 21535 Tr	rim, Plastic Insert, For Recessed Base, became production	

DOOR HINGES AND GLASS ILLUSTRATION



DOOR HINGES AND GLASS PARTS LIST				
PART NO.	PART DESCRIPTION	QTY.	NOTE	
1	Assembly, Foamed Door, 39"	1	See Door External Parts For Door P/N's	
3000	Screw, TEK 8-18	9		
3004-06	Carriage Bolt, ¼-20, ¾"	4		
3009-02	Rivet, Pop, Steel, 1/8 Diameter	6		
3018-06	Screw, ¼ X ¾, Self Tapping, Hex Head	20	For Glass Retainers	
3153-11	Nut, Hex With Lock Washer	4		
3234	Lamp Cover, T8, 24", Clear, With End Caps	1	VCF Option	
3240	Lamp Cover, T8, 36", Clear, With End Caps	1	VCF Option	
3279	Lamp Cover, T8, 18", Clear, With End Caps	1	VCB Option Make by Cutting 3240 in Half	
20091	Retainer, Horizontal, Eyelet	2		
20092	Retainer, Vertical, Eyelet	2		
20206	Hinge, Washer Plate	2		
20302	Assembly, Hinge, Top (Black), Door	1		
20303	Assembly, Hinge Bottom, Door	1		
20330-03	Trim, Extruded Edge, 26.76 (Required for Glass), Hor.	2	Use with Glass	
20330-04	Trim, Extruded Edge, 42.00 (Required For Glass), Vert.	2	Use with Glass	
20481	Window, Glass, 1-1/8" Triple Pane (39")	1		
20615	Retainer, Triple Pane Glass, Vertical	2	Use with 20629	
20616	Retainer, Triple Pane Glass, Bottom Ver. 3 (39")	1	Use with 20629	
20617	Retainer, Triple Pane Glass, Top (39")	1	Use with 20629	
20629	Window, Glass, Triple Pane (39")	1	Use with 21482 Door	
20726-01	Lamp Bracket, 36" Vertical	1	For VCF Dual Light Option	
20729	Lamp Cover, 36" Vertical	1	Clear Polycarbonate	
20733-01	Lamp Bracket, 24" Vertical	1	For VCF Dual Light Option	
20734	Lamp Cover, 24" Vertical	1	Clear Polycarbonate	
20852	Seal, T-Handle, Low Temp	1	,	
20857	Lock Bolt Alignment Bracket	1		
20965	Tray Restraint, Low Temp, Reduced Depth	1		
21042	Retainer, 1-1/8" Triple Pane Glass, Top (39")	1	Use with 20841	
21043	Retainer, 1-1/8" Triple Pane Glass, Vertical (39")	1	Use with 20841	
21044	Retainer, 1-1/8" Triple Pane Glass, Bottom (39")	1	Use with 20841	
21910	Lamp Bracket, Horizontal, Low Temp (35")	1	For VCB Option	
22068	Assembly, Lock Bolt Cover, Low Temp, Ver. E.	1		


DOOR, PRODUCT HOPPER WITH SENSIT I ILLUSTRATION



DOOR, PRODUCT HOPPER WITH SENSIT I PARTS LIST					
PART NO.	PART DESCRIPTION	QTY.	NOTE		
1	Assembly, Foamed Door, 39"	1	See Door External Parts For Door P/N's		
3000	Screw, TEK 8-18	15	(Estimated Quantity)		
3009-04	Rivet, Pop, Steel, 1/8 x 1/4 Grip	8	(Estimated Quantity)		
3015	Bearing, Nyliner Snap-In	4			
3017-10	Washer, Flat Steel, SAE Std., #10 Screw 7/32 X ½	6			
3046	Bumper	2	Nylon Rivet/Fastener		
3113	Pushnut, 3/16" Stud	2			
3185	Emitter Board	1	For Sensing Product Inside Hopper		
3186	Detector Board	1	For Sensing Product Inside Hopper		
20108	Vend Door, Shaft (39")	1			
20247	Product Kicker, Left	1			
20248	Product Kicker Right	1			
20252	Sensor, Emitter Board	1			
20261	Sensor Diffuser	1			
20328	Deflector Plate (39")	1	Use if not using Gum and Mint or 1.5" Tray		
20338	Assembly, Vend Hopper, 39" (square bottom)	1	See Note Below		
20780	Assembly, Bottle Hopper (tapered back)	1	See Note Below		
20345	Emitter Mounting Bracket Assembly	1			
20429	Deflector Plate, Gum And Mint (Used W/Gum And Mint), Right	1	Rivet To Hopper		
20429-01	Deflector Plate, Gum And Mint (Used W/Gum And Mint), Left	1	Rivet To Hopper		
20518	Assembly, Sensor	1	Order 20518 And 20541 as Assembly 20816		
20541	Sensor, Detector Board 2	1	Order 20518 And 20541 as Assembly 20816		
20816	Assembly, Detector and Housing With Anti-Fog Lens	1	•		
20910	Assembly, Aligned Diffuser	1			
20964	Assembly, Vend Door, 39"	1			
21099	Deflector Plate, Reduced Depth, 39" (Top Bent Back 45°)	1	Use if not using Gum and Mint or 1.5" Tray		
21609	Deflector, 1.5 Helix Tray, RH	1	Rivet To Back Of Hopper (Top Bent Back 45°)		
21609-01	Deflector, 1.5 Helix Tray, LH	1	Rivet To Back Of Hopper (Top Bent Back 45°)		
21457	Product Kicker, Left, Ver. 2	 1			
21459	Product Kicker, Right, Low Temp, Ver. 2	1			
21460	Product Kicker, Without Flange, Left, Ver. 2	 1	Use For Milk Trays		
21462	Product Kicker, Without Flange, Right, Low Temp, Ver. 2	<u>'</u> 1	Use For Milk Trays		
21645	Emitter Board, Sensit I	1	OSS FOR WHIRE Frays		
	NTE: Frank Vander C.N. 0040 4444 (40/00/00) and often all 20" was die	ı	ill be a suite and with the best less as a suite		

GENERAL NOTE: From Vendor S.N. 0046-1114 (10/29/02) and after, all 39" vending machines will be equipped with the bottle hopper only.

DOOR, HOPPER WITH SENSIT II ILLUSTRATED





	DOOR HOPPER WITH SENSIT II PARTS LIST					
PART NO.	PART DESCRIPTION	QTY.	NOTE			
1	Assembly, Foamed Door, 39"	1	See Door External Parts for Door P/N's			
3000	Screw, TEK 8-18	28	(Estimated Quantity)			
3002-04	Screw, Machine, Type F, 8-32	4	3/4" Long, Self-Tap, Phillips, Round Head			
3009-04	Rivet, Pop, Steel, 1/8 x 1/4 Grip	8	(Estimated Quantity)			
3015	Bearing, Nyliner Snap-In	4				
3017-10	Washer, Flat Steel, SAE Std., #10 Screw 7/32 X 1/2	6				
3025-24	Grommet, Rubber, 1-1/2 ID x (1-3/4 OD X .062 Groove)	1	Harness Pass-Through			
3113	Pushnut, 3/16" Stud	2				
3237	Tape, 3/8 x 1/4", Urethane Foam, Adhesive Backed	15"	Cut To Lengths As Required			
20108	Vend Door, Shaft (39")	1				
20247	Product Kicker, Left	1	(Left Hand When Facing Front Of Door)			
20248	Product Kicker Right	1				
20328	Deflector Plate (39")	1	Apx. 6.5" High			
20429	Deflector, Gum and Mint Tray, RH	1	Rivet To Back Of Hopper For G&M Tray			
20429-01	Deflector, Gum and Mint Tray, LH	1	Rivet To Back Of Hopper For G&M Tray			
21099	Deflector Plate, Reduced Depth (39")	1	45° Bend At Top			
21628	Assembly, Vend Hopper, Low Temp	1				
21383	Detector, Delivery Sensor, Sensit II	1				
21384	Emitter, Delivery Sensor, Sensit II	1				
21385	Detector, Product Sensor, Sensit II	1				
21386	Emitter, Product Sensor, Sensit II	1				
21413	Assembly, Delivery Sensor Detector Bracket, Sensit II	1				
21415	Assembly, Delivery Sensor Emitter Bracket, Sensit II	1				
21418	Assembly, Delivery Sensor Detector Cover, Sensit II	1				
21420	Assembly, Delivery Sensor Emitter Cover, Sensit II	1				
21442	Assembly, Product Sensor Emitter Bracket, Sensit II	1				
21443	Assembly, Product Sensor Detector Bracket, Sensit II	1				
21457	Product Kicker, Left, Ver. 2	1				
21459	Product Kicker, Right, Low Temp, Ver. 2	1				
21460	Product Kicker, Without Flange, Left, Ver. 2	1	Use For Milk Trays			
21462	Product Kicker, Without Flange, Right, Low Temp, Ver. 2	1	Use For Milk Trays			
21609	Deflector, 1.5 Helix Tray, RH	1	Rivet To Back Of Hopper When Using 1.5" Tray			


21609-01	Deflector, 1.5 Helix Tray, LH	1	Rivet To Back Of Hopper When Using 1.5" Tray
21613	Lens, Product Sensor Bracket, Sensit II	2	
21651	Assembly, Vend Door, Low Temp (39")	1	
21690	Enclosure, Door Switch, Ver 2	1	Normally Closed Switch, P/N 3036
21692	Plate, Fan Switch Striker, Ver. 2	1	Above Detector Sensor
22044	Assembly, Vend Hopper With Wireway, Sensit II (39")	1	For Doors With Plastic Liners
22045	Assembly, Vend Hopper With Product Sensors and Wireway,	1	For Doors With Plastic Liners
	Sensit II (39")		


GENERAL NOTE: From Vendor S.N. 0046-1114 (10/29/02) and after, all 39" vending machines will be equipped with the bottle hopper only.

ELECTRICAL HARNESS ILLUSTRATIONS












(SAME CONNECTOR ON BOTH ENDS)


20144, HARNESS, REFERIGERATION











20148, HARNESS, MOTOR DISTRIBUTION

































20904, HARNESS, CONTROL POWER AND REFRIGERATION RELAY, LEFT SIDE DOOR SWITCH











21425 HARNESS, DELIVERY SENSOR DETECTOR/CONTROL, SENSIT II



















21591, HARNESS, CONTROL POWER AND REFRIGERATION RELAY, LEFT SIDE DOOR SWITCH, SENSIT II






ELECTRICAL HARNESS PARTS LIST					
PART NO.	PART DESCRIPTION	QTY	NOTES		
20117	Temperature Sensor, Harness	1	Sensit I, Integral to Sensor		
20141	Harness, Power Distribution	1			
20142	Power Cord Assembly, U.S.	1	U.S. Use		
20143	Harness, Display	1	Same Connector Both Ends		
20144	Harness, Refrigeration, (Not Labeled)	1	For Chiller Power		
20146	Harness, Door Motors	1			
20147	Harness, Tray, 10 Column	1	Use For 5 Column Tray		
20148	Harness, Motor Distribution	1			
20154	Harness, R.F.I. Filter Ground	1			
20158	Harness, Multi-Drop Bus	1			
20160	Harness, Gum and Mint	1			
20161	Harness, Sensor	1			
20163	Harness, Tray, 8 Column	1	Use For 4 Column Tray		
20199	Keypad, Harness	1	Integral to Keypad		
20563	Harness, Ballast, Assembly 2	1	VCB Option		
20564	Harness, Lamp 2	1	VCB Option, Attaches to Lamp Bracket		
20679	Harness, Vend Hopper Product Sensor	1	Sensit I		
20698	Harness, Evaporator Fan Switch	1			
20701	Harness, Transformer and Fuse	1			
20718	Harness, Dual Lamp, 110VAC	1	VCF Option		
20730	Harness, Ballast, Dual Lamp, 110VAC	1	VCF Option, Attaches to Lamp Bracket		
20897	Harness, Dual Transformer	1	VCF Option		
20893	Harness, Power Distribution, Integral Socket	1	VCF Option		
20899	Harness, Window Heater Transformer	1			
20904	Harness, Control Power and Refrigeration Relay, Left Side Door Switch	1			
21405	Harness, Refrigeration Relay T9A	1			
21425	Harness, Delivery Sensor Detector/Control, Sensit II	1			
21426	Harness, Delivery Sensor Detector/Emitter, Sensit II	1			
21427	Harness, Product Sensor Emitter, Sensit II (Optional)	1			
21428	Harness, Product Sensor Detector, Sensit II (Optional)	1			
21432	Harness, Display, Sensit II	1			

21468	Temperature Sensor, and Harness, Sensit II	1	Integral to Sensor, for Chiller
21480	Harness, Control Board Ground	1	
21484	Harness, Power Distibution, Integral Socket, On/Off Switch	1	
21485	Harness, On/Off Switch	1	
21584	Harness, 1.5" Helix Tray	1	
21591	Harness, Control Power & Refrigeration Relay, Left Side Door Switch, Sensit II	1	
21592	Harness, Executive Mech Connector, Sensit II	1	
21909	Harness, Window Heat, Low Temp (35")	1	

GENERAL NOTE: Sensit (sometimes called Sensit I) and Sensit II are different designs. A Sensit II harness will only work in a vendor equipped with the Sensit II system.


1.5" HELIX TRAY ILLUSTRATION



1.5" HELIX TRAY PARTS LIST						
PART NO.	PART NAME	QTY	NOTES			
3000	Screw, TEK 8-18	18				
3009-02	Rivet, Pop, Steel, 1/8	34				
3246	Latch, Nylon, Gum and Mint	2				
3247	Strike, Nylon, Gum and Mint	2				
20086	Motor, Single Helix W/O Switch	4				
20236	Extrusion, Gum and Mint Rail	2				
20237	Extrusion Mount, Upper (Gum and Mint)(Right Side)	1				
20237-01	Extrusion Mount, Upper (Gum and Mint)(Left Side)	1				
20238	Extrusion Mount, Lower (Gum and Mint)(Right Side)	1				
20238-01	Extrusion Mount, Lower (Gum and Mint)(Left Side)	1				
20465-04	Extrusion, Price Marker, Reduced Height	1				
20973	Rail, Gum and Mint, Reduced Depth (39")(Right Side)	1				
20973-01	Rail, Gum and Mint, Reduced Depth (39")(Left Side)	1				
21196	Doubler, Tray 1.5" Helix Tray	1				
21197	Tray Body, 1.5" Helix Tray	1				
21199	Tray Back, 1.5" Helix Tray	1				
21200	Tray Inner Side, 1.5" Helix Tray	2	Parts Are Factory Assembled As A Unit			
21201	Tray Inner Section, 1.5" Helix Tray	2				
21202	Tray Inner Mid Section, 1.5" Helix Tray	1				
21203	Divider, Tray, 1.5" Helix Tray, RH	4				
21203-01	Divider, Tray, 1.5" Helix Tray, LH	4				
21204	Tray Slide Channel,1.5" Helix Tray, RH	1				
21204-01	Tray Slide Channel,1.5" Helix Tray, LH	1				
21206	Helix Adapter, 1.5" Helix Tray	4				
21207-15	Helix, 1.5" Tray, Counterclockwise, Black	2	Standard Tray is Equipped With Two Of Each			
21207-25	Helix, 1.5" Tray, Counterclockwise, Black	2				
21523	Bracket, Stop, 1.5" Helix Tray	2				
21584	Harness, 1.5" Helix Tray	1				


General Note: The 1.5 Helix Tray has replaced the 20668 Gum and Mint Tray.

BOTTLE TRAY ILLUSTRATION



BOTTLE TRAY PARTS LIST					
PART NO.	PART DESCRIPTION	QTY.	NOTE		
3001-03	Screw, Sheet Metal, Type B, 8-18	6			
3009-02	Rivet, Pop, Steel, 1/8	81			
3015	Bearing, Nyliner, Snap-In	2	Use On 20691 And 20724 for Bottle Tipper		
3017-05	Washer, Flat Steel	10	For Rivet Reinforcement		
3021	Protective Cap, Vinyl	7			
3042-01	Wire Tie, Panel Mount	1			
3111	Helix Ejector, Small Helix	8			
3189-01	Tape, UHMW Polyethylene, 3/4" X .005"	16'			
20086	Motor, Single Helix W/O Switch	8			
20163	Harness, Tray, 8 Column	1			
20465-03	Extrusion, Price Marker, Ver. 2	1			
20644	Tray Doubler, Bottle (39')	1			
20672	Tray Corner, Bottle, Right	1	Use With 20690 Without Bottle Tipper		
20690	Assembly, Bottle Tipper Bar	1			
20691	Tray Corner, Bottle Tipper Bar, Right	1	Use With 20690 For Bottle Tipper		
20692	Device, Bottle Alignment	8			
20724	Tray Corner, Bottle Tipper Bar, Left	1	Use With 20690 For Bottle Tipper		
20725	Tray Corner, Bottle, Left	1	Use With 20690 Without Bottle Tipper		
20775	Tray Reinforcement, Bottle (39') Ver. 2	1			
20796-01	Edge Guard, Tray Corner (Only RH)	1	Use On 20672 Without Bottle Tipper		
20796-02	Edge Guard, Tray Corner (Only RH)	1	Use On 20691 For Bottle Tipper		
20956	Tray Divider, Reduced Depth (Square Front)	7			
20960	Tray Body, Bottle, Reduced Depth (39')	1			
20962	Bracket, Bottle Tray Rail, Reduced Depth (RH)	1			
20962-01	Bracket, Bottle Tray Rail, Reduced Depth (LH)	1			
20966	Helix Adapter, Without Hub	8			
20980	Rail, Bottle Tray, Reduced Depth (RH)	1	Use Lower Rivet Positions For Tall Bottles		
20980-01	Rail, Bottle Tray, Reduced Depth (LH)	1	Use Lower Rivet Positions For Tall Bottles		
21276	Tray Divider, Reduced Depth, Tapered Front	7	3.3" High		
21336	Helix, 3' Counter-Clockwise, 3.5' Opening, Black	8	See Helix Description For Options.		
21374	Tray Divider, Reduced Depth, Tapered Front, High	7	4.9" High		
21475-02	Rail Slide, Full Extension, 24"	1	1 Pair		

GUM AND MINT TRAY ILLUSTRATION




	GUM AND MINT TRAY PARTS LIST				
PART NO.	PART DESCRIPTION	QTY	NOTE		
3000	Screw, Sheet Metal, TEK-8-18	12			
3009-02	Rivet, Pop, Steel, 1/8 X 1/4	44			
3042-01	Wire Tie, Panel Mount (1")	1			
3046	Bumper	2			
3246	Latch, Nylon, Gum And Mint	2			
3247	Strike, Nylon, Gum And Mint	2			
20087	Motor, Single Helix With Switch	4			
20160	Harness, Gum And Mint Tray	1			
20223	Housing, Product Stripper (Gum And Mint)	4			
20224	Product Stripper (Gum And Mint)	4			
20225	Crank, Product Stripper (Gum And Mint)	4			
20226	Screen, Product Retainer (Gum And Mint)	4			
20227	Flipper Base	4			
20228	Flipper	4			
20229	Pusher (Gum And Mint)	4			
20230	Pusher Spring Hub (Gum And Mint)	4			
20231	Tray (Gum And Mint)	1			
20233	Front Brace (Gum And Mint)	1			
20234	Rear Brace (Gum And Mint)	1			
20235	Tray Slide Channel (Gum And Mint)	1			
20235-01	Tray Slide Channel (Gum And Mint)	1			
20236	Extrusion, Gum And Mint Rail	2			
20237	Extrusion Mount Upper (Gum And Mint)	1			
20237-01	Extrusion Mount Upper (Gum And Mint)	1			
20238	Extrusion Mount Lower (Gum And Mint)	1			
20238-01	Extrusion Mount Lower (Gum And Mint)	1			
20239	Divider, Gum And Mint (RH)	4			
20239-01	Divider, Gum And Mint (LH)	4			
20241	Rail, Cross Brace, Gum And Mint	1			
20242	Spring, Retainer, Gum And Mint	1			

20274	Spring, Flipper (Gum And Mint)	4			
20300	Housing Top Plate	4			
20327	Pusher, Spring, Gum And Mint	4			
20422	Divider Shim, Gum And Mint	4			
20434	Tray Lid, 2 Piece, Gum And Mint	1			
20435	Flange, Tray Lid, 2 Piece, Gum And Mint	1	Part of Assembly 20705		
20646	Latch, Spring, Gum And Mint	1	Part of Assembly 20703		
20796-03	Edge Trim, Tray Corner	2			
20705	Assembly, Lid, Gum And Mint	1			
20973	Rail, Gum and Mint, Reduced Depth (39") (Right Side)	1	For 39" Vendors		
20973-01	Rail, Gum and Mint, Reduced Depth (39") (Left Side)	1	For 39" Vendors		

General Note: The 20668 Gum and Mint Tray has been replace by the 1.5 Helix Tray.

THIS PAGE INTENTIONALLY LEFT BLANK


HELIX ILLUSTRATIONS




HELIX PARTS LIST						
PART NO.	HELIX DESCRIPTION *	SLOT (VEND) WIDTH	NUMBER OF SLOTS (PITCH)	HELIX OUTSIDE DIAMETER	TURNS	NOTE
20119-07	Helix, Small CW, Black	2 5/8	7	2.6	CW	Use With 20120-07 As A Set
20120-07	Helix, Small CCW, Black	2 5/8	7	2.6	CCW	
20119-10	Helix, Small CW, Black	1 7/8	10	2.6	CW	Use With 20120-10 As A Set
20120-10	Helix, Small CCW, Black	1 7/8	10	2.6	CCW	
20120-12	Helix, Small CCW, Black	1 7/8	12	2.6	CCW	
20120-15	Helix, Small CCW, Black	1 7/8	15	2.6	CCW	
20120-18	Helix, Small CCW, Black	1 7/8	18	2.6	CCW	
20120-24	Helix, Small CCW, Black	1 7/8	24	2.6	CCW	
21207-15	Helix, 1.5", CCW, Black	1	15	1.5	CCW	Use in 1.5" Helix Tray
21207-25	Helix, 1.5", CCW, Black	9/16	25	1.5	CCW	Use in 1.5" Helix Tray
21336	Helix, 3", CCW, Black	3.5	6	3	CCW	Bottle Tray
21337	Helix, 3", CCW, Black	3.2	6	3	CCW	Bottle Tray
21465-5	Helix, 3.75" CCW, Black	3 1/4	5	3.75	CCW	Large
21465-7	Helix, 3.75" CCW, Black	2 5/8	7	3.75	CCW	Large
21465-9	Helix, 3.75" CCW, Black	2	9	3.75	CCW	Large
21465-10	Helix, 3.75" CCW, Black	1 3/4	10	3.75	CCW	Large
21465-12	Helix, 3.75" CCW, Black	1 ½	12	3.75	CCW	Large
21465-15	Helix, 3.75" CCW, Black	1 1/4	15	3.75	CCW	Large

General Note: Please call AMS if a helix with a special pitch is required. Also, the quantity of helixes required depends on the vendor configuration.

UNIVERSAL (FOOD/SNACK/CANDY) TRAY ILLUSTRATION



UNIVERSAL (FOOD/SNACK/CANDY) TRAY PARTS LIST (5-COLUMN SET-UP SHOWN)					
PART NO.	PART DESCRIPTION	QTY.	NOTE		
1	Helix	5	Refer to Helix Section.		
3001-03	Screw, Sheet Metal, Type B, #8-18 (3/8" Long)	4			
3009-02	Rivet, Pop, Steel, 1/8 (1/8" Grip)	12			
3019	Canoe Clip	12			
3020	Wire Tie, Standoff	1			
3021	Divider Cap	4			
3042-01	Wire Tie, Panel Mount	1			
3111	Helix Ejector	5			
3295-03	Rivet, Pop, Steel, 1/8, Domed, Plain	10			
20073	Tray Stop (Rh)	1			
20073-01	Tray Stop (Lh)	1			
20086	Motor, Single Helix	5			
20133	Tray Divider Spring	4			
20147	Harness, Tray, 10 Column	1			
20202	Helix Alignment Device	5	Qty determined by set-up.		
20220	Extrusion, Candy Pusher	8			
20221	Bar, Candy Pusher	4			
20465-02	Extrusion, Price Marker, Reduced Height	1			
20544	Tray Doubler, Ver. 2 (39")	1			
20545	Tray Corner, Ver. 2 (Rh)	1			
20545-01	Tray Corner, Ver. 2 (Lh)	1			
20614	Label Sheet, Reduced Height Price	1	Use on extrusion 20465-02 only		
20796-01	Edge Trim, Tray Corner	1			
20955	Tray Body, Reduced Depth, (39")	1	23.89" Long.		
20956	Tray Divider, Reduced Depth	4			
20984	Tray Divider, High, Reduced Depth	4	For Tall Product		
20966	Helix Adapter, without Hub	5			
22040	Label Sheet, Numeric, Reduced Height, Location	1	For Numeric Keypad: Use on 20465-02		
21064	Assembly, Reduced Depth Rail	1	For Universal Tray, Right Hand		
21064-01	Assembly, Reduced Depth Rail	1	For Universal Tray, Left Hand		



THIS PAGE INTENTIONALLY LEFT BLANK